
Model: LK(S)3050 LED Ceiling/Wall Lighting Fixture



Installation Instructions

IMPORTANT:

- · Wall or Ceiling mount only.
- Before commencing installation Isolate all cables at the point of installation from the building supply mains.
- Installation by a Registered Electrician is recommended.
- Choose the mounting position carefully taking into account the fixing method, the services behind the wall and the IP rating required for that position.



DO NOT disassemble the LED unit or the electronic driver – NO user serviceable parts are inside.

Connect the supply cable to the terminal block on the back of the LED lamp assembly.

Connect the Neutral wire to terminal N

Connect the Phase wire to terminal L

Twist lock the lamp assembly into the base.

Fit the diffuser to the colour cover ring, and fasten to the base with the 4 screws.

SENSOR MODEL:

Important: This uses micro wave sensor technology – persons and objects moving toward the sensor are detected the best. **Detection Angle is 360 Degrees.**

- **1. Time adjustment is from 5 seconds to 15 minutes.** For setting the detection zone and performing the walk test it is recommended to select the shortest time
- 2. Dusk / dawn, ambient light operating adjustment is 2, 10, 50 lux or disable. When installing set the adjustment to disable, to allow the walk test at daytime.
- **3. Distance sensitivity adjustment is up to 8 metres.** Select 100%, 75%, 50%, or 10% most accurate when mounted at 2.5 metres height, set with walk test.
- **4. Re-adjust time and dusk / dawn settings,** following the walk test adjustment.

Trouble Shooting:

- If operating inadvertently, check that the lighting fixture is mounted securely and the distance setting.
- If not operating, check that the isolating switch is On and check both distance and daylight settings.

!!! Please leave this page with the installation.

NOTE: This LED luminaire does not have a replaceable lamp or serviceable parts. **Do Not Open.** Consult a Registered Electrician.

