


# SFE model Striplights – How to change the tube

**1**




Remove the two end caps by giving a firm tug sideways

**2**




Remove plastic cover lens by pulling

**3**



To remove the tube:  
Hold at both ends,  
Push down gently then twist

**4**



You should now be able to see the pins of the tube are in line with the slot, now pull the tube out holding at both ends